CMOS Single Photon Detectors

Edoardo Charbon AQUA - LAP - CSCT

Ecole Polytechnique Fédérale, Lausanne (EPFL)

Acknowledgements

The <u>AQUA Group</u> was started in June 2003. It is funded by the Swiss National Science Foundation and Logitech



Cristiano Niclass




Dr. Max Sergio



Ties Kluter



Randhir K. Singh



Claudio Favi




Huan Du




Dr. Claudio Bruschini



Chantal Schneeberger




Abhishek Garg




Marek Gersbach

The World Is Analog



Typical Measurement Process



Quantization in time and amplitude

In Reality...

- The world is not analog but measurable by quanta
- The analog measurement is the result of a conversion of the true signal
- Every conversion introduces errors

Quanta → Analog Signal → Digital

Why not Skipping Analog?

Quanta → Digital

<u>Example</u>: photons → digital pulses

Outline

- Why, when, where?
- Single Photon Avalanche Diodes (SPADs)
- 3D Imaging
- 2D Imaging
- Conclusions & future work
- Acknowledgements

Why, When, Where?

Why Do We Care?

- Single photon detectors (SPDs) are entering the mainstream
- They will be found in medium to high volume applications

Examples:


- Secure Telecom (private key distribution systems) [Gisin/UniGe, IdQuantique, SensL]
- Optical Telecom [Boser/UCB, Pister/UCB, Dust Networks]
- True Random Number Generators [Popovic/EPFL, IdQuantique]
- High sensitivity (L³) videocams [Cork Univ., QinetiQ, e2v]
- 3D videocams for gaming applications [***]
- Low dose X-ray imaging [Hamamatsu, Fairchild Imaging]

SPDs in Science

- Molecular count/detection
- Neuro-activity scanning (dye¹-based)
- Fluorescence correlation spectroscopy (FCS)
- Two-photon spectroscopy
- Fluid-dynamics research
- Non-ionizing imaging (transillumination)

¹⁾ Dye is a substance composed of nanoparticles which change reflectivity depending on potential

Neuro-activity Scanning





Neuro-activity Scanning (Cont.)

 $\Delta I \approx 10^{-3} I$ for $\Delta I >> \sigma^2(I) = I^{1/2}$

→ must work with ultra-high intensities


but, most CCDs and CMOS APS are <u>saturated</u>





[Grinvald et al., 2001]

Fluorescence Correlation Spectroscopy



→ <u>Picosecond time resolution</u> is needed to build sufficiently precise characterization

Bioluminescence Detection


Principle

 Luciferase based assay methods (550nm) used to detect pathogens, proteins and DNA sequencing

Features:


- Sensitivity: 10-6Lx

- pixel size: 250x250um



[Eltoukhy et al., ISSCC 2004]

Fluid-dynamics Research



Single Photon Projects

Current


- 3D camera
- Near-saturation cortical imaging (EPFL-LS)
- High-speed digital camera (Industry)
- High-speed shutter digital camera (Columbia University)

Near future

- Ultra-high speed Calcium Flux in neurons (EPFL-LS)
- 3D long-distance camera (Industry)
- Free space com (Academia)
- Transillumination (EPFL-MT)


Single Photon Avalanche Diodes (SPADs)

Photoelectric Effect




Parameters: QE, p, λ

Avalanche Effect




Parameters: QE, p, λ

SPAD Operating in Geiger Mode



[Rochas, TransED, 2002]


- In avalanche mode:
 - $<G> \cong 1000$
- In Geiger mode:
 - <G>→ ∞
 - → avalanche must be stopped




SPAD Operating in Geiger Mode

passive quenching:

operation cycle:






- One photon → one cycle (dead time definition)
- Thermally generated carriers → dark counts


Dark Counts

Intuition:


Traps capture photocharges and release them randomly (by diffusion, tunneling, etc.) → avalanche is triggered → spurious pulses



CMOS SPAD (ISSCC04)




$$V_{op} = VDD + |V_H| > V_{bd}$$




Main features of the pixel

- dead time: 32ns
- PDP: ~ 12% @ 635nm
- dark count rate typ. 350Hz
- timing jitter: < 50ps

SPAD Evolution (ISSCC05)





Features

- Pitch reduction
- Column routing mechanism
- MOS Quenching resistance

3D Imaging

Goal

- Find distance to each point in the scene (<u>rangefinding</u>)
- Build depth map of the scene

Specific 3D Applications

- Surveying
 - Geo, construction
- Automotive
 - Airbag deployment
 - Collision detection/avoidance
- Security
 - facial recognition
 - room volumetric analysis
- Consumer
 - Human-computer interfaces
 - VR
- Medical/Research
 - Optical tomography
 - Bio-chemical & molecular analysis

Electronic Theodolites


Some specifications

Sub-mm precision

~100m range


Low fps(?)





Face Recognition

- Some specifications
 - 600um~1mm precision
 - 1~2m range
 - 30 fps



Virtual (Planar) Keyboard

- Some specifications
 - 2mm precision
 - 20~30cm range
 - -50-70 fps



3D Imaging:

optical Time-of-flight (TOF)

Rangefinding


Methods

- Interferometry
- Triangulation
- Time-of-flight (TOF)

Principle

- Light
- RF
- Ultrasound
- Magnetism

Optical TOF Based Rangefinding



$$d = (c/2) TOF$$

Conventional Approaches

- Single highly sensitive detector with mechanical scanning device
- Problems:
 - → high-cost
 - → non-portable
- Array of conventional CMOS detectors with high-power optical source
- Problems:
 - → 10~100W peak power
 - → potentially unsafe


Our Approach

- Array of Single Photon Avalanche Diodes (SPADs) fabricated in CMOS process
- Pros:
 - Milliwatt laser source (peak power)
 - Compact
 - Low cost


3D Imaging:

System Architecture


Sensor Architecture




Sensor Photomicrograph



Electro-Optical System




TOF Computing




3D Imaging:

Measurements


Time Resolution



Distance



Model



High resolution Camera: 20cm x 20cm view

Depth Map Example

Lateral resolution:


64x64 pixels

Depth resolution:

- 1.3mm (wc)

Range:

-3.75m





[Niclass and Charbon, ISSCC 2005]

Companion Techniques

- Multi-exposure super-resolution techniques
 - Microscanning (x-/y- piezo elements)
 - S/R algorithm (LCAV, Prof. Vetterli)
- CMOS time-to-digital-converter (TDC) Integration
 - Current resolution: 100ps (0.8μm)
 - Target (under test): 25ps (0.18μm)

Microscanning Mechanism





CMOS Time-to-Digital-Converter


- CMOS TDC (RSUT)
- Resolution:100ps
- Accuracy:<30ps
- Clock: 40MHz

3D Performance Summary

Parameter	32x32	64x64
W.C. axial uncertainty $\sigma(d)$	1.8mm	1.3mm
(10k meas.)		
Axial range	0.15 ~ 4m	0.15 ~ 3.75m
Single measurement uncertainty $\sigma(\tau)$	268ps	350ps
Opt. peak/average power	100mW/0.5mW	250mW/0.7mW
Repetition rate	50MHz	40MHz
Light pulse width	100ps	100ps
Chip power dissipation	<1mW	< 6mW

2D Imaging

CCDs (e.g.)




Three conversions:

Photons $\rightarrow q \rightarrow V \rightarrow D$

Five sources of noise:

Shot, 1/f, kT/C, read-out, ADC

Conventional CMOS APS (e.g.)




Performance of Interest

- Dynamic range
 - Ratio between the smallest detectable and maximum detectable intensity
- SNR
 - Ratio between signal due to intensity and noise
- FPS
 - Frames-per-second
- Pitch
 - Distance between pixels
- ... and FPN, smearing, blooming, color, etc.

Limiting Factors

- Miminum # detectable photons
- Noise
 - Read-out noise
 - kT/C noise
 - 1/f noise
- Saturation
 - Limited number of available charges
- Speed (10kfps)

Imagers Based on SPADs



SPAD Arch Limiting Factors

- Miminum # detectable photons
 - Limited by DCR
- Noise
 - Read-out noise
 - kT/C noise
 - 1/f noise
- Saturation
 - Limited by dead time and read-out bandwidth
- Speed
 - Shown 250kpps

New Challenges


Departure from amplitude based imager

- **→** Therefore:
 - Local evaluation of intensity
 - Intensity storage
 - Digital noise
 - Low-power operation


Example:

- R rows
- share column of bandwidth B ≤ $1/t_D$ Then, in average every pixel has B/R bandwidth, thus dynamic range ≈ $20\{Log(B/R)-Log(DCR)\}$
- Architecture directly influences Performance


Importance of Pixel Timing




Experimental Setup for Imager




DCR







Sensitivity and Dynamic Range




Linearity



Photon Detection Probability



Example



High resolution Camera: 20cm x 20cm view



SPAD Camera: 32x32pixels

High Speed Example


Features


- No measurable thermal noise (Poisson noise dominates)
- No measurable cross-talk, blooming, smearing



[Niclass, Rochas, Besse, Popovic, and Charbon, Transducers 2005]

High Sensitivity Example





Intensity Performance Summary

Parameter	Value
Minimum Integration Time	4μs
Maximum Pixel Dynamic Range	120dB
Optical Intensity @ SNR=0dB	1.3x10 ⁻³ Lx
Dark Count Rate (DCR) T=room/0°C	350Hz/75Hz
Pixel Fillfactor	1.1%
Photon Detection Probability (PDP)	1-26%

Conclusions

- Significance and applications of 3D imaging
- Fabricated 1k pixel SPAD array in standard CMOS technology
- psec (μm) accuracy reached with mW laser source
- Chip power dissipation <1mW
- High sensitivity, dynamic range, and linearity for 2D applications

Future Work

- VGA pixel arrays
- Count / Read-out parallelization
- Pixel-level and column-level time-to-digital converters (TDCs)
- Pitch reduction
- On-chip basic computation
- Color

Future Directions

- qCAD
- Single photon telecommunications
- Accelerated DNA sequencing
- Laserless ultra-short range quantum communication and computing
- Data management

http://aqua.epfl.ch